## CL222 & CL254 for dinghy halyards

These suggestions are based on our tests with a variety of halyard ropes.



CL222 CL222AN







Use 1 x CL222 for low loads on small dinghies.



Use 2 x CL222 (one behind the other) for high loads on racing dinghies.



Use CL254 for 5mm halyard ropes.



Use CL254 for 6mm halvard ropes.

When correctly tensioned, the cleat always holds the same part of the halyard. This can cause rope wear and halyard slip.

## Suggestion:

Every year, untie the top of the halyard from the sail headboard. Cut about 5cm (2"), from the top of he halyard. Re-fix to the sail. A new part of the rope is then gripped in the cleat.

This will give your halyard a much longer life.

www.clamcleat.com

CL222 search

CL254 search